



Mark the Top of the piston travel on the crank case and flywheel, this is TDC

Place the disc and align the TDC with the crank case mark

Then make a second mark on the crank case aligning with the appropriate degrees

This is where the points should just start to open